



NOTES:

1. BEND T-LOCK FLAP TO ATTACH TO FORMS. AFTER FORMS ARE STRIPPED BEND FLAP ONTO CONCRETE & ATTACH TO  $\frac{3}{32}$  PLAIN SHEET WITH WELD STRIP. PATCH BOLT HOLES AS REQUIRED

						<b>Ameron</b> PROTECTIVE LINING DIVISION	
						ATTACHING T-LOCK TO TOP OF METAL FORMS	
						DRAWN	P.K. 7-86
						APPV'D	PLD-TL-022
						REV	0
SYMBOL	REVISION	DATE	BY	APPV'D	APPV'D		