



NOTES:

1. JOIN T-LOCK SECTION ON OUTLET FORMS WITH 1 INCH FLAT WELD STRIP. WELD FROM TEE SIDE OF SHEET.

2 CUT HOLE IN T-LOCK SHEET AFTER CONCRETE IS CAST.

3 THE SMALL GAP BETWEEN SECTIONS OF T-LOCK MAY BE FUSED TOGETHER IF REQUIRED, USING A HOT AIR WELDING GUN.

4. FOR JOINT WELD SEE DETAIL PLD-TL-010

Ameron PROTECTIVE LINING DIVISION

SMALL DIAMETER OUTLET LINED
T-LOCK (LESS THEN 18" DIAMETER)

DRAWN P.K. 7-86
APPV'D

PLD-TL-052

REV
B

REVISID 4-94