



BEND AND APPLY  
1" WELD STRIP  
AFTER FORM REMOVAL

NOTES:

1. ATTACH LARGER T-LOCK SHEET TO COLUMN FORMS WITH NAILS AND 2 WAY TAPE PRIOR TO INSTALLING FOURTH SIDE OF COLUMN FORM.
2. FASTEN SMALLER T-LOCK SHEET TO FOURTH SIDE OF FORMS
3. FOR JOINT WELD SEE DETAIL PLD-TL-010

**Ameron** PROTECTIVE LINING DIVISION

APPLICATION OF T-LOCK  
COLUMN DETAILS

DRAWN	P.K.	9-86	PLD-TL-093	REV
APPV'D				0