



NOTE: USING THE 19Y ADHESIVE SYSTEM ATTACHE THE 2 X 2 ANGLE TO THE METAL FRAME. THEN DRY PACK THE CAVITY AS REQUIRED.

FOLD 2 X 2 ANGLE OVER DRY PACK AND WELD TO EXISTING T-LOCK WITH 1" WELD STRIP.

**Ameron** PROTECTIVE LINING DIVISION

TERMINATION OF T-LOCK LINER AT METAL FRAME

DRAWN JPG 5/07  
 APPV'D JP

PLD-TL-360

REV  
 0